


Whirlpool LCE4332PQ0 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: LCE4332PQ0
(White)



8180484

5

Whirlpool [Residential Whirlpool LCE4332PQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	326018423			Fabric Softener Dispenser Assembly
2	8182228			Filter, Lint
3	8182296			Screw, Agitator
4	8182227			Agitator
5	326000116	326001402		Ring-Tub
6	8182229			Balance Ring
7	8182298	489491		Screw 8-18 X 5/8
8	8182302	285709		Hub
9	8182301	3428430		Screw
10	8182303			Saddle Block
11	8182230			Basket
12	8182300	3934714		Screw
13	326033908			Tub
14	326036378			Sleeve, Tub Overflow
15	326036377			Bag, Tub Overflow
16	326033906			Shield, Tub/Motor

