


Whirlpool LCE4332PQ1 02 - CONTROLS AND REAR PANEL PARTS

CONTROLS AND REAR PANEL PARTS

For Model: LCE4332PQ1
(White)



8180597

3

Whirlpool Residential Whirlpool LCE4332PQ1 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	326032994			Inlet Valve
2	326032997			Inlet Valve
3	326033919			Seal, Inlet Valve
4	326018823			Screw
5	326027101			Bracket, Inlet Valve
6	326033923			Overlay
7	326048437			Interface Board
8	326048436			Control, Electronic
9	326041720			Screw
10	326034589			Switch, Water Level
11	326046803	326013200		Hose, Pressure Switch
12	326034866			Shield, Controls
13	8182293	1181135		Screw
14	326034862	356499		Bracket, Hose Storage
15	326034647			Connector, Drain Hose
16	326048456			Hose Coupler Assembly

17	326037688	16123	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
18	326038497	285655	Clamp, Hose
19	326048253		Power Cord Assembly
20	326032995		Harness, Wiring
21	326041720		Screw
22	326044485		Bracket, Pressure Switch Mounting
23	326039784	W10254672	Adapter Faucet

