


# Whirlpool LCR5232HQ2 03 - AGITATOR, BASKET AND TUB PARTS



3970461

5

Whirlpool [Residential Whirlpool LCR5232HQ2 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3428670	<a href="#">326018423</a>		Fabric Softener Dispenser Assembly
2	3428391	<a href="#">8182228</a>		Filter, Lint
3	<a href="#">3969019</a>			Vacuum Break Assembly
4	3428392	<a href="#">285999</a>		Agitator
5	<a href="#">3968262</a>			Tub Ring
6	3428186	<a href="#">326050300</a>		Basket
8	<a href="#">3968473</a>			Tub And Inlet Assembly
9	3430159	<a href="#">353244</a>		Hose, Pressure Switch
10	<a href="#">3430339</a>			Hose, Bleach
11	<a href="#">3400872</a>			Screw, 8-18 X 3/8
12	370452	<a href="#">596669</a>		Clamp, Manifold
14	<a href="#">3428814</a>			Shield, Tub/Motor
17	<a href="#">3400061</a>			Screw, Dispenser Housing Mounting
18	3934565	<a href="#">326050300</a>		Basket
19	<a href="#">3966238</a>			Hose, Tub Overflow

20

3429682

[3400872](#)

Screw, 8-18 X 3/8

21

[3968381](#)

Seal

24

[3968185](#)

Clamp, Hose

