


Whirlpool LCR7244HQ2 02 - CONTROLS AND REAR PANEL PARTS

CONTROLS AND REAR PANEL PARTS

For Model: LCR7244HQ2
(White)



3970462

3

Whirlpool Residential Whirlpool LCR7244HQ2 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	16123			Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3935155			Bracket-Valve
3	3935357			Extension, Start-Pause
4	3429189			Screw
5	3935875			Clip, Harness
6	3970436	3970626		Control-Elec
7	3935929			Jumper-Wire
8	3966810	3430161		Hose Coupler Assembly
9	3970202			Harness, Control Board
10	3935353			Seal
11	3935602			Screw, Switch Mtg.
12	3966789			Switch, Water Level
13	3967605		Not Available	Bracket, Control (Must Order No. 3 And No. 39.)
14	3970203			Harness, Lid Switch

15	3970204		Harness, Pressure Switch
17	3969225		Hose, Pressure Switch
18	3967755		Valve, Water Mixing
19	3429563	2205813	Strap
20	3935354		Seal, Pressure Switch
21	3934036	Not Available	Screw, Control Board (3)
22	62863	3390631	Screw, 10-16 X 3/8
24	3935672	285945	Clip
29	3935995		Shield, Water Valve
30	370448	616099	Clamp
32	3429900		Hose, Pump To Tub
33	3966202		Switch, Cycle Selection
34	3935634	Not Available	Screw, Top Shield (2)
35	3966208		Switch, Water Temperature
38	3400038	489437	Screw, 10-16 X 1/2
39	3935527		Panel, Console
40	3970443	285936	Shield
41	3934148		Screw, 10-16 X 1/2
42	3400038	489437	Screw, 10-16 X 1/2
43	3970235	487944	Washer
47	3950759	3957796	Knob, Control
49	3428526	Not Available	Grommet, Pump (3)
50	356054		Cap, Threaded
51	3430186	8280537	Rivet, Shield
52	356499		Bracket, Hose Storage

the laundry company[®]

the laundry company[®]