


Whirlpool LCR7244HQ2 08 - MISCELLANEOUS PARTS - OPTIONAL PARTS (NOT INCLUDED)

MISCELLANEOUS PARTS

For Model: LCR7244HQ2
(White)



3970462

11

Whirlpool [Residential Whirlpool LCR7244HQ2 Washer Parts](#) Parts Diagram 08 - MISCELLANEOUS PARTS - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3374592	W10254672		Adapter Faucet
2	356138			Clamp, Hose
3	3428855	285654		Parts-Misc
4	661581			Clamp, Hose
5	3347868	W10339879		Tie, Cable
6	16123			Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
"	72017			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	N/A		Not Available	COUPLING
"	384496			Coupling, Hose Extension Kit
"	BLANK		Not Available	CONVERSION KIT

"	3430190	285677	Conv-Kit
"	3935674	285768	Stationary To Portable
"	BLANK		Not Available
"	49971		DRYER STACK STAND
"			Dryer Stack Stand

