


Whirlpool LEQ8611LW1 01 - TOP AND CONSOLE PARTS



03-03 Litho in U.S.A. (djc)

1

Part No. 8180014

Whirlpool [Residential Whirlpool LEQ8611LW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|---------------|--|
| 1 | LIT8541832 | | Not Available | Literature Parts (Wiring Diagram) |
| " | LIT8522243 | | Not Available | Literature Parts (Guide, Use & Care) |
| " | LIT8535833 | | Not Available | Literature Parts (Instructions Installation) |
| " | N/A | | Not Available | Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS |
| " | LIT677818 | 677818L | | Diy |
| 2 | 8317305 | 285909 | | Panel-Rear |
| 3 | 3406725 | | | Timer Assembly |
| 4 | 3400859 | | | Screw, Grounding |
| 5 | 3398095 | | | Switch, Push-To-Start |
| 6 | 3391885 | | | Connector, Edge |
| 7 | 3395683 | | | Receptacle, Multi-Terminal |
| 8 | 8271359 | 279962 | | Endcap |
| " | 8271362 | 279965 | | Endcap |

| | | | |
|----|-------------------------|---------------------------|---|
| 9 | 8271316 | | Bracket, Control |
| 10 | 3390646 | W10139210 | Screw, 8-18 X 5/16 |
| 11 | 8538957 | | Knob, Control |
| " | 8538958 | | Knob, Control |
| 12 | 388326 | | Screw, 8-18 X 1.25 |
| 13 | 688805 | | Clip, Spring Knob |
| 14 | 3391018 | | Tie Cable |
| 15 | 694419 | | Mini-Buzzer |
| 16 | 3397269 | | Connector, Timer |
| 17 | 693995 | | Screw, Hex Head |
| 18 | 3347243 | | Block, Disconnect |
| 19 | 8299958 | | Harness, Electric |
| 20 | 8538953 | | Timer Knob Assembly |
| " | 8538954 | | Timer Knob Assembly |
| 21 | 8530152 | | Switch, Temperature |
| 22 | 8318255 | 8568314 | Strap, Console |
| 23 | 357213 | | Nut, Push-In |
| 24 | 8271399 | 3979278 | Top |
| " | 8271401 | 3979279 | Top |
| 25 | 3405156 | | Switch, Rotary |
| 26 | 8271365 | 279962 | Endcap |
| " | 8271368 | 279965 | Endcap |
| 28 | 8317342 | W10119283 | Cover, Terminal Block |
| 29 | 3390537 | 8558178 | Control, Electronic |
| 30 | 3390814 | 90767 | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 31 | 8532623 | | Panel, Control |
| " | 8532624 | | Panel, Control |
| 32 | 3955775 | 8303811 | Badge, Assembly |
| 33 | 8536939 | | Clip, Knob |
| 34 | 3936144 | | Do-It-Yourself Repair Manuals |
| 35 | 3390647 | 488729 | Screw |
| 37 | 3401144 | | Connector |
| 41 | 3394427 | | Clip-Harness |
| 44 | 94614 | | Terminal |

