


Whirlpool LER3622PQ2 02 - CABINET PARTS



Whirlpool Residential Whirlpool LER3622PQ2 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	343641	681414		Screw, 10AB X 1/2
2	695201	280050		Relief-Strain
3	348726			Base Assembly
4	660658			Clamp, Motor Mounting 343481 685441
5	8538265	8539558		Motor-Drive
6	697776	4331106		Screw, No.10-32 X 7/16
7	696541			Bracket, Motor
8	8066084			Bushing, Snap
9	691366			Idler And Pulley Assembly
10	3397659			Block, Terminal
11	3393657			Restrainer, Belt
12	8066051			Pulley, Motor
13	3393008	308685		Side Trim)
14	3396795			Cover, Terminal Block
15	8066064	3394652		Belt, Drive
16	348705			Panel, Side

17	690259	279304	Block-Term
18	3406104	3406105	Door Switch Assembly
19	697773	3395530	Screw
20	693943	280044	Panel
21	8572767		Thermal Limiter 195 F
22	8066123	279264	Air Channel Box
23	345670		Lock, Top
24	3389441		Door Catch Assembly
25	348023		Hinge And Pin Assembly
26	696144	279570	Latch
27	3390734		Seal, Door
28	694091		Trim, Side Right Hand
29	695656	280077	Door
30	348205		Door, Front
31	8562104		Handle, Door
32	3390631		Screw, 10-16 X 3/8
33	233550		Foot
34	3394083		Clip, Front Panel
35	98234		Clip, U-Bend

