


Whirlpool LER3624JQ2 02 - CABINET PARTS

CABINET PARTS

For Model: LER3624JQ2
(Designer White)



8180296

3

Whirlpool [Residential Whirlpool LER3624JQ2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8541400			Bracket, Cabinet
2	3393008	308685		Side Trim)
4	343641	681414		Screw, 10AB X 1/2
5	3396795			Cover, Terminal Block
6	3396807	280040		Panel-Rear
7	694091			Trim, Side Right Hand
8	3406102			Door Switch Assembly
9	697773	3395530		Screw
10	693995			Screw, Hex Head
11	3392100	49621		Feet-Leveling
12	8530603	8533643		Cabinet
13	98234			Clip, U-Bend
14	690363	18776		Lock, Front Top
15	693197	280062		Panel
16	685203	279220		Clip
17	3389441			Door Catch Assembly

18	348023	Hinge And Pin Assembly	
19	3394083	Clip, Front Panel	
20	696144	279570	Latch
21	695656	280077	Door
22	348205	Door, Front	
23	686711	Handle, Door	
24	8066123	279264	Air Channel Box
25	279393	Terminal Block Screw Kit	
26	3397659	Block, Terminal	
27	238088	8066217	Hinge, Top
28	691366	Idler And Pulley Assembly	
29	8066065	341241	Belt
30	348780	Base, Motor	
31	3400500	Bolt, 3405245 5/16-18 X 3/4	
32	3394341	W10299847	Pulley-Motor
33	8538262	279827	Motor-Drve
34	660658	Clamp, Motor Mounting 343481 685441	
35	3404162	Clamp, Motor	
36	3390734	Seal, Door	
37	697776	4331106	Screw, No.10-32 X 7/16
38	279318	Terminal Tinned And Brass Panel	
39	342055	488627	Screw

