


Whirlpool LER6646PW0 03 - BULKHEAD PARTS, OPTIONAL PARTS (NOT INCLUDED)



8180511

5

Whirlpool [Residential Whirlpool LER6646PW0 Dryer Parts](#) Parts Diagram 03 - BULKHEAD PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">348368</a>			Lint Chute Assembly
2	<a href="#">8066086</a>			Plug, Drum Hole
3	3390647	<a href="#">488729</a>		Screw
4	<a href="#">3388703</a>			Washer, Support
5	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
6	3977393	<a href="#">279816</a>		Cutoff-Tml
7	<a href="#">347139</a>			Seal, Lint Chute
8	<a href="#">3977373</a>			Bracket, Drum Light
9	<a href="#">3403636</a>			Baffle, Drum
10	<a href="#">694089</a>			Wheel, Blower
11	8557384	<a href="#">8577230</a>		Housing, Blower
12	3398161			CLIP
13	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
14	<a href="#">8541818</a>			Box, Heater

15	<a href="#">3977767</a>		Thermostat, High Limit 250 F
16	<a href="#">3394196</a>		Seal, Blower Shaft
17	3403585	<a href="#">279838</a>	Element
18	<a href="#">279457</a>		Wire Kit, Terminal
19	<a href="#">3392519</a>		Thermal Limiter
20	<a href="#">3387134</a>		Thermostat, Internal-Bias
21	<a href="#">690997</a>		Washer, Thrust
22	3399506	<a href="#">W10359270</a>	Shaft, Drum Roller Threads
23	3399507	<a href="#">W10359269</a>	Shaft, Drum Roller Threads
24	3397588	<a href="#">349241T</a>	Support
25	<a href="#">348197</a>		Washer, Support
26	<a href="#">3359452</a>		Nut, Lock
27	<a href="#">3403413</a>		Bulkhead
28	692526	<a href="#">279441</a>	BeaRng-Rng
29	97787	<a href="#">W10109200</a>	Screw, Baffle Mounting
30	3406130	<a href="#">279857</a>	Seal
31	<a href="#">695587</a>		Drum Assembly
32	<a href="#">692490</a>		Baffle, Drum
33	<a href="#">3976434</a>		Bracket, Support Shaft
34	<a href="#">90296</a>		Nut, Push On
35	<a href="#">339956</a>		Seal, Air Duct To Bulkhead
36	<a href="#">489463</a>		Screw, 8-18 X 1/16
37	<a href="#">696302</a>		Shield, Exhaust
38	3403634	<a href="#">W10136369</a>	Socket, Drum Light Assembly
39	3406124	<a href="#">22002263</a>	Lamp
40	3402841	<a href="#">8532165</a>	Lens, Drum Light
41	487909	<a href="#">488729</a>	Screw
	N/A	Not Available	ACCESSORY PARTS
"	279948	<a href="#">4392065</a>	Kit, Dryer Repair
"	<a href="#">8522199</a>		Accessory Parts
"	<a href="#">72017</a>		Paint, Touch-Up
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )

