


Whirlpool LEW0050PQ2 01 - CABINET AND DOOR PARTS



CABINET AND DOOR PARTS

For Model: LEW0050PQ2
(White)

COMPACT
ELECTRIC DRYER



8-06 Litho in U.S.A. (djc)

1

Part No. 8180821

Whirlpool Residential Whirlpool LEW0050PQ2 Dryer Parts Parts Diagram 01 - CABINET AND DOOR PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8183096		Not Available	Use & Care Guide
"	8182608			Wiring Diagram
2	8182406			Frame, Door Outer
3	8183106			Retainer Insert
4	8182333	W10253196		Screw
5	8182516			Glass, Door
6	8182414			Frame, Inner Door
7	8183105			Gasket, Door
8	8182518			Screw
9	8182503			Toe Panel
10	BLANK		Not Available	Front Panel (Not Serviced)
11	8182479			Foot, Adjustable
12	8182338	489355		Screw, 8 X 1/2
13	8182459	3400843		Orifice Holder
14	8183097			Spring, Thermostat
15	8182480		Not Available	BASE

16	8182401		Screw, Door Catch
17	8182490	489491	Screw 8-18 X 5/8
18	8182534		Cover, Drum Shaft Support
19	8182533		Support, Drum Shaft
20	8182412	3400843	Orifice Holder
21	8182323	3179776	Screw
22	8182509		Side Panel
23	8182535		Panel, Lower Rear
24	8182574		Kit, Door Handle
25	8182511		Bracket, Front Panel
26	8182531		Plate, Door Switch
27	8182530		Door Switch
28	8182411	489491	Screw 8-18 X 5/8
29	BLANK	Not Available	Door Hinge (Not Serviced)
30	BLANK	Not Available	Rivet, Hinge (Not Serviced)
32	8183109		Cross-Bar, Cabinet
33	8182526		Screw, Element Cover
34	8182524		Top
35	8182338	489355	Screw, 8 X 1/2
36	8182507		Seal, Rear Drum
37	8182540		Retaining Ring, Rear Seal
38	8182590		Panel, Rear
39	8182506		Nut, Power Cord
40	8182514		Cover, Terminal Block
41	8182525		Terminal Block
42	8182513		Mounting Bracket, Terminal Block
43	8183104		Wire Harness
44	8182520		Side Panel
45	8182528		Heater Element
46	8182505		Plate, Thermostat
47	8182491	4358271	Screw
48	8182508		Thermostat, 194 F
49	8182502		Thermostat,
51	8182510		Cover, Inlet
52	8183110		Cover, Element

