


# Whirlpool LEW0050PQ2 02 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Model: LEW0050PQ2  
(White)



8180821

3

Whirlpool [Residential Whirlpool LEW0050PQ2 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8182338	<a href="#">489355</a>		Screw, 8 X 1/2
2	8182521	<a href="#">280109</a>		Kit, Control Panel
4	8182576	<a href="#">280110</a>		Switch And Button Assembly
5	<a href="#">280112</a>			Switch And Button Assembly
6	8183107	<a href="#">8182522</a>		Timer And Indicator Light Assembly
7	<a href="#">8182575</a>			Button, Push
8	8182323	<a href="#">3179776</a>		Screw
9	<a href="#">8182361</a>			Spring, Knob
10	<a href="#">8182519</a>			Knob
11	<a href="#">8182532</a>			Lens, Indicator
12	8182577	<a href="#">280111</a>		Switch And Button Assembly