


Whirlpool LEW0050PQ3 02 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: LEW0050PQ3
(White)



W10113986

3

Whirlpool [Residential Whirlpool LEW0050PQ3 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182338	489355		Screw, 8 X 1/2
2	8182521	280109		Kit, Control Panel
4	8182576	280110		Switch And Button Assembly
5	8182395			Switch And Button Assembly
6	8183107	8182522		Timer And Indicator Light Assembly
7	8182575			Button, Push
8	8182323	3179776		Screw
9	8182361			Spring, Knob
10	8182519			Knob
11	8182532			Lens, Indicator
12	8182577	280111		Switch And Button Assembly