


Whirlpool LGN1000PQ0 01 - TOP AND CONSOLE PARTS OPTIONAL PARTS (NOT INCLUDED)



5-04 Litho in U.S.A. (djc)

1

Part No. 8180387

Whirlpool Residential Whirlpool LGN1000PQ0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS OPTIONAL PARTS (NOT INCLUDED)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8533770		Not Available	Literature Parts (Sheet, Cycle Feature)
"	LIT8535830		Not Available	Literature Parts (Instructions, Installation)
"	LIT8522243		Not Available	Literature Parts (Guide, Use & Care)
"	LIT8528187		Not Available	Literature Parts (Wiring Diagram)
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT677818	677818L		Diy
2	8539888			Jumper, Wire
3	694419			Mini-Buzzer
4	8271365	279962		Endcap
5	717252			Receptacle, Terminal
8	8271359	279962		Endcap

9	693995		Screw, Hex Head
10	8557857		Screen, Lint
13	688983	487240	Screw, For Mtg. Service Capacitor
14	3400859		Screw, Grounding
15	3395683		Receptacle, Multi-Terminal
16	8557930	8563985	Top
18	8544935		Knob, Control
19	3394427		Clip-Harness
20	388326		Screw, 8-18 X 1.25
21	3976584		Timer Assembly
24	3397269		Connector, Timer
26	3403499		Connector, 2-Position
27	3403498		Connector, 3-Position
29	3390646	W10139210	Screw, 8-18 X 5/16
30	357213		Nut, Push-In
31	8299877		Harness, Wiring
34	8274261		Do-It-Yourself Repair Manuals
36	8536939		Clip, Knob
39	3404233		Switch, Push-To-Start
48	8544955		Timer Knob Assembly
52	94614		Terminal
53	8271418		Bracket, Control
54	8545971		Panel, Control
55	3936144		Do-It-Yourself Repair Manuals
"	N/A	Not Available	ACCESSORY PARTS
"	3404351		Accessory Parts
"	279948	4392065	Kit, Dryer Repair
"	346764		Kit, Hold Down
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

