


# Whirlpool LGQ8000JQ5 01 - TOP AND CONSOLE PARTS



11-05 Litho in U.S.A. (LT)

1

Part No. 6180881

Whirlpool Residential Whirlpool LGQ8000JQ5 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8535832		Not Available	Instructions, Installation
"	8578195		Not Available	Use & Care Guide
"	3406668		Not Available	Wiring Diagram
"	8535896		Not Available	Sheet, Cycle Feature
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	<a href="#">3401684</a>			Jumper, Wire
3	<a href="#">694419</a>			Mini-Buzzer
4	8271365	<a href="#">279962</a>		Endcap
5	<a href="#">717252</a>			Receptacle, Terminal
6	<a href="#">3405154</a>			Switch Rotary
7	<a href="#">8316736</a>			Switch, Temperature
8	8271359	<a href="#">279962</a>		Endcap
9	<a href="#">693995</a>			Screw, Hex Head

10	<a href="#">349639</a>		Handle And Lint Screen Assembly
11	<a href="#">8283378</a>		Cover, Lint Screen
12	3978605	<a href="#">W10044470</a>	Hinge, RH
"	<a href="#">3978606</a>		Hinge, Lint Lid
13	688983	<a href="#">487240</a>	Screw, For Mtg. Service Capacitor
14	8533951	<a href="#">3400859</a>	Screw, Grounding
15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	8271390	<a href="#">8521918</a>	Top
17	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
18	<a href="#">3957799</a>		Knob, Control
19	<a href="#">3394427</a>		Clip-Harness
20	<a href="#">388326</a>		Screw, 8-18 X 1.25
21	<a href="#">3406725</a>		Timer Assembly
22	<a href="#">8558178</a>		Control, Electronic
23	<a href="#">3391885</a>		Connector, Edge
24	<a href="#">3397269</a>		Connector, Timer
25	<a href="#">3401144</a>		Connector
26	<a href="#">3403499</a>		Connector, 2-Postion
27	<a href="#">3403498</a>		Connector, 3-Position
28	<a href="#">688805</a>		Clip, Spring Knob
29	8533971	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
30	<a href="#">357213</a>		Nut, Push-In
31	<a href="#">8299890</a>		Harness, Wiring
33	<a href="#">3347243</a>		Block, Disconnect
34	<a href="#">8274261</a>		Do-It-Yourself Repair Manuals
35	297535	<a href="#">17258</a>	Bumper
39	<a href="#">3398095</a>		Switch, Push-To-Start
48	<a href="#">3957754</a>		Timer Knob Assembly
52	<a href="#">94614</a>		Terminal
53	<a href="#">8271418</a>		Bracket, Control
54	<a href="#">3977825</a>		Panel, Control
55	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals

