


Whirlpool LGR3624PQ0 02 - CABINET PARTS



8180404

3

Whirlpool Residential Whirlpool LGR3624PQ0 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	4331106		Screw, No.10-32 X 7/16
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	8541400			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3394975			Plug, Front Panel
7	3396807	280040		Panel-Rear
8	342055	488627		Screw
10	3406102			Door Switch Assembly
11	697773	3395530		Screw
14	694091			Trim, Side Right Hand
15	3394083			Clip, Front Panel
16	3392100	49621		Feet-Leveling
18	8530603	8533643		Cabinet
19	98234			Clip, U-Bend
20	690363	18776		Lock, Front Top

21	3394895	280022	Panel
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	348023		Hinge And Pin Assembly
26	696144	279570	Latch
27	695656	280077	Door
28	348205		Door, Front
29	686711		Handle, Door
30	8066123	279264	Air Channel Box
31	3390734		Seal, Door
32	344020	3401402	Cord, Power
33	238088	8066217	Hinge, Top
34	691366		Idler And Pulley Assembly
35	8066065	341241	Belt
36	348780		Base, Motor
37	3400500		Bolt, 3405245 5/16-18 X 3/4
38	3394341	W10299847	Pulley-Motor
39	8538262	279827	Motor-Drve
40	660658		Clamp, Motor Mounting 343481 685441
41	3404162		Clamp, Motor
42	8318272	W10465748	Burner-Gas
43	341029		Clamp, Pipe Door Spring

