


Whirlpool LGR5636LT1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

29" GAS DRYER

For Models: LGR5636LQ1, LGR5636LT1
(Designer White) (Biscuit)



04-04 Litho In U.S.A. (djc)

1

Part No. 8180327

Whirlpool Residential Whirlpool LGR5636LT1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8535830		Not Available	Literature Parts (Instructions, Installation)
"	LIT8522243		Not Available	Literature Parts (Guide, Use & Care)
"	LIT8528187		Not Available	Literature Parts (Wiring Diagram)
"	LIT8522245		Not Available	Literature Parts (Sheet, Cycle Feature (For Model LEQ5000KQ1))
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT677818	677818L		Diy
2	3400859			Screw, Grounding
3	3394427			Clip-Harness
4	8271365	279962		Endcap
"	8271368	279965		Endcap
5	3397269			Connector, Timer
6	8274261			Do-It-Yourself Repair Manuals

7	3395683		Receptacle, Multi-Terminal
8	8271359	279962	Endcap
"	8271362	279965	Endcap
9	694419		Mini-Buzzer
10	349639		HANdle And Lint Screen Assembly
11	8283378		Cover, Lint Screen
"	8283380		Cover, Lint Screen
12	3978605	W10044470	Hinge, RH
"	3978606		Hinge, Lint Lid
13	688983	487240	Screw, For Mtg. Service Capacitor
14	3401674		Wire, Jumper
15	693995		Screw, Hex Head
16	8271390	8521918	Top
"	8271392	8521920	Top
17	297535	17258	Bumper
18	3405152		Switch, Wrinkle Shield
19	8283292	8283276	Wire, Jumper
20	8271341	3957804	Knob, Push-To-Start
"	8271349		Not Available Knob, Push To Start (Biscuit)
21	3976584		Timer Assembly
22	3403499		Connector, 2-Position
23	3403498		Connector, 3-Position
25	688805		Clip, Spring Knob
29	3390646	W10139210	Screw, 8-18 X 5/16
30	357213		Nut, Push-In
31	8299877		Harness, Wiring
32	8536939		Clip, Knob
39	3977456		Switch, Push-To-Start
48	8312687	3957754	Timer Knob Assembly
"	8271404	3957755	Timer Knob Assembly
49	8271339	3957799	Knob, Control
"	8271348	3957797	Knob, Push-To-Start
50	717252		Receptacle, Terminal
51	3347243		Block, Disconnect
52	94614		Terminal
53	8271418		Bracket, Control
54	8532635		Panel, Control
"	8532636		Panel, Control
55	3936144		Do-It-Yourself Repair Manuals
56	388326		Screw, 8-18 X 1.25

the laundry company[®]