


# Whirlpool LGR6646PW1 04 - BULKHEAD PARTS, OPTIONAL PARTS (NOT INCLUDED)



8180884

7

Whirlpool [Residential Whirlpool LGR6646PW1 Dryer Parts](#) Parts Diagram 04 - BULKHEAD PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">348368</a>			Lint Chute Assembly
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">3406022</a>			Bracket, Bulkhead
4	<a href="#">3388703</a>			Washer, Support
5	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
6	<a href="#">3392519</a>			Thermal Limiter
7	<a href="#">347139</a>			Seal, Lint Chute
8	<a href="#">3387134</a>			Thermostat, Internal-Bias
9	<a href="#">8066086</a>			Plug, Drum Hole
10	<a href="#">694089</a>			Wheel, Blower
11	<a href="#">8577230</a>			Housing, Blower
12	3398161			CLIP
13	<a href="#">489463</a>			Screw, 8-18 X 1/16
14	8530285	<a href="#">279980</a>		Box

15	<a href="#">3403140</a>		Thermostat, High-Limit 205F
16	<a href="#">280010</a>		Kit, Thermal Cut-Off
17	<a href="#">3401707</a>		Jumper, Tco-High Limit
18	<a href="#">8066049</a>		Funnel, Burner Light
19	3390647	<a href="#">488729</a>	Screw
20	<a href="#">696302</a>		Shield, Exhaust
21	<a href="#">3403636</a>		Baffle, Drum
23	<a href="#">690997</a>		Washer, Thrust
24	3399506	<a href="#">W10359270</a>	Shaft, Drum Roller Threads
25	3399507	<a href="#">W10359269</a>	Shaft, Drum Roller Threads
26	3397590	<a href="#">349241T</a>	Support
27	<a href="#">348197</a>		Washer, Support
28	<a href="#">3359452</a>		Nut, Lock
29	<a href="#">3403413</a>		Bulkhead
30	<a href="#">338906</a>		Radiant, Sensor
31	692526	<a href="#">279441</a>	BeaRng-Rng
32	97787	<a href="#">W10109200</a>	Screw, Baffle Mounting
33	3406130	<a href="#">279857</a>	Seal
34	<a href="#">695587</a>		Drum Assembly
35	<a href="#">692490</a>		Baffle, Drum
36	<a href="#">3976434</a>		Bracket, Support Shaft
37	<a href="#">90296</a>		Nut, Push On
38	<a href="#">339956</a>		Seal, Air Duct To Bulkhead
39	<a href="#">3977373</a>		Bracket, Drum Light
40	3403634	<a href="#">W10136369</a>	Socket, Drum Light Assembly
41	3406124	<a href="#">22002263</a>	Lamp
42	3402841	<a href="#">8532165</a>	Lens, Drum Light
43	487909	<a href="#">488729</a>	Screw
	N/A	Not Available	ACCESSORY PARTS
"	279948	<a href="#">4392065</a>	Kit, Dryer Repair
"	<a href="#">346764</a>		Kit, Hold Down
"	<a href="#">8522199</a>		Accessory Parts
"	<a href="#">72017</a>		Paint, Touch-Up
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )

