


Whirlpool LHW0050PQ1 02 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: LHW0050PQ1
(White)



8180820

3

Whirlpool [Residential Whirlpool LHW0050PQ1 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182348			Control Panel
2	8182725			Button
3	8182350			Housing
4	8182720			Screw
5	8182351			Control, Pcb
6	8182353			Support
7	8182354			Shield
8	8182355	98006631		Screw
9	8182352	W10253196		Screw
10	8182356			Led, Pcb
11	8182357			Gasket
12	8182358			Cable
13	8182359			Cable, Ribbon
14	8182360			Knob
15	8182361			Spring, Knob
16	8182362			Push Button

17

[8182724](#)

Switch, Cycle

18

[8182346](#)

Switch, Spin Speed

19

[8182723](#)

Switch, Spin Speed

21

[8182395](#)

Switch And Button Assembly

