


Whirlpool LHW0050PQ1 04 - DISPENSER PARTS



8180820

5

Whirlpool [Residential Whirlpool LHW0050PQ1 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|--------|--------------------|
| 1 | 8182371 | | | Handle, Drawer |
| 2 | 8182729 | | | Overlay |
| 3 | 8182383 | | | Pin |
| 4 | 8182730 | | | Spring |
| 5 | 8182367 | | | Housing, Dispenser |
| 6 | 8182370 | | | Drawer, Detergent |
| 7 | 8182377 | 8182720 | | Screw |
| 8 | 8182727 | | | Cover, Drawer |
| 9 | 8182376 | 487353 | | Screw |
| 10 | 8182378 | | | Dispenser |
| 11 | 8182375 | | | Clamp, Hose |
| 12 | 8182323 | 3179776 | | Screw |
| 13 | 8182373 | 285988 | | Hose |
| 14 | 8182372 | | | Cover, Bleach |
| 15 | 8182379 | | | Link |
| 16 | 8182366 | | | Actuator |

| | | | |
|----|-------------------------|-------------------------|-------------------|
| 17 | 8182365 | | Bracket, Actuator |
| 18 | 8182364 | | Arm |
| 19 | 8182389 | | Hose, Fill |
| " | 8182397 | | Hose, Fill |
| 20 | 8182390 | | Washer |
| 21 | 8182387 | | Water Valve |
| " | 8182398 | | Water Valve |
| 22 | 8182380 | | Connector |
| 23 | 8182381 | 8182399 | Hose |
| 24 | 8182374 | | Clamp, Hose |
| 25 | 8182386 | 8182399 | Hose |
| 26 | 8182396 | 285452 | Hose Screen |
| 27 | 8182399 | | Hose |
| 28 | 8182728 | 8182399 | Hose |
| 29 | 8182726 | | Spring |

