


Whirlpool LHW0050PQ3 01 - TOP AND CABINET PARTS



8-06 Litho in U.S.A. (djc)

1

Part No. 8180938

Whirlpool Residential Whirlpool LHW0050PQ3 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8183111		Not Available	Use & Care Guide
"	8183130		Not Available	Wiring Diagram
"	8182569		Not Available	Energy Guide
2	8182721			Cover, Filter
3	8182719			Top
4	8182589			Panel, Rear
5	8182325			Clamp, Hose
6	8182338	489355		Screw, 8 X 1/2
7	8182324			Clamp, Hose
8	8182319			Bottom Plate
9	8182323	3179776		Screw
10	BLANK		Not Available	Hinge (Not Serviced)
11	8182321			Clip, Harness
12	8182322			Support, Harness
13	8182328			Clip
14	8182643			Electronic Control

15	8182333	W10253196	Screw
16	BLANK	Not Available	Cabinet (Not Serviced)
17	8182331		Bracket
18	8182332		Shield
19	8182334		Foot, Leveling
20	8182337		Nut
21	8182643		Electronic Control
22	8182342		Bracket, Control
23	8182388		Switch, Pressure
24	8182341	489355	Screw, 8 X 1/2
25	8182645		Filter
26	8182392		Power Cord
27	8183088		Harness, Main
28	8182690		Microswitch, Door
29	8182718		Bracket
30	8182401		Screw, Door Catch
31	8182731		Strain Relief
32	8182732		Screw

