


Whirlpool LHW0050PQ4 02 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: LHW0050PQ4
(White)



W10114819

3

Whirlpool [Residential Whirlpool LHW0050PQ4 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182348			Control Panel
2	8182725			Button
3	8182350			Housing
4	8182323	3179776		Screw
5	8182351			Control, Pcb
6	8182353			Support
7	8182354			Shield
8	8182355	98006631		Screw
9	8182352	W10253196		Screw
10	8182356			Led, Pcb
11	8182357			Gasket
12	8182358			Cable
13	8182359			Cable, Ribbon
14	8182360			Knob
15	8182361			Spring, Knob
16	8182362			Push Button

17	8182724	Switch, Cycle
18	8182723	Switch, Spin Speed
19	8182345	8169479 Screw, Grille
21	8182395	Switch And Button Assembly

