


Whirlpool LHW0050PQ4 04 - DISPENSER PARTS



W10114819

5

Whirlpool Residential Whirlpool LHW0050PQ4 Washer Parts Parts Diagram 04 - DISPENSER PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182371			Handle, Drawer
2	8182729			Overlay
3	8182383			Pin
4	8182730			Spring
5	8182367			Housing, Dispenser
6	8182370			Drawer, Detergent
7	8182377	8182720		Screw
8	8182727			Cover, Drawer
9	8182376	487353		Screw
10	8182378			Dispenser
11	8182375			Clamp, Hose
12	8182323	3179776		Screw
13	8182373	285988		Hose
14	8182372			Cover, Bleach
15	8182379			Link
16	8182366			Actuator

17	8182365		Bracket, Actuator
18	8182364		Arm
19	8182389		Hose, Fill
"	8182397		Hose, Fill
20	8182390		Washer
21	8182387		Water Valve
"	8182398		Water Valve
22	W10119091	8182380	Connector
23	W10119092	8182399	Hose
24	8182374		Clamp, Hose
25	W10119094	8182399	Hose
26	8182396	285452	Hose Screen
27	8182399		Hose
28	W10119093	8182399	Hose
29	8182726		Spring

