


Whirlpool LSB6300LW3 06 - WIRING HARNESS PARTS



8160173

9

Whirlpool [Residential Whirlpool LSB6300LW3 Washer Parts](#) Parts Diagram 06 - WIRING HARNESS PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3349557			Retainer, Harness
2	388498		Not Available	Clip, Harness
3	3347812	8528351		Clip
4	3352501	8559320		Restraint, Hose
5	90016			Clip, Pressure Switch Hose
6	3390496	8281256		Clip, Harness
7	389379			Retainer, Side To Feature Panel
8	3948614			Disconnect Block
9	352089			Timer, Block Disconnect
10	62889			Receptacle, Terminal
11	353424			Plug, Terminal
12	62505			Block, Disconnect
13	3347243			Block, Disconnect
14	63523			Harness, Protector
15	717252			Receptacle, Terminal
16	3352944			Clip, Harness

17	3390423	Not Available	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)
18	3347730	Not Available	Receptacle, (6-Way) (Use Term. 94613)
19	3349494		Connector, Etc
20	3407125	3955728	Control, Etc
21	3948617	2172937	Connector
22	3360056		Connector
23	3354925		Block, Connector
24	3354926		Block, Connector

