


# Whirlpool LSB6300PW1 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Model: LSB6300PW1  
(White/Grey)

AUTOMATIC  
WASHER



7-04 Litho in U.S.A. (drd)

1

Part No. 8180493

[Whirlpool Residential Whirlpool LSB6300PW1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3956025		Not Available	Installation Instructions
"	3955869		Not Available	Use & Care Guide
"	3955907		Not Available	Feature Sheet
"	3956911		Not Available	Energy Guide
"	8564019		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	<a href="#">4313896</a>			Do-It-Yourself Repair Manuals
2	8543451	<a href="#">8543447</a>		Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	<a href="#">3976348</a>			Absorber, Sound
8	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting

10	<a href="#">9724509</a>		Bumper, Lid
11	<a href="#">8318084</a>		Switch, Lid
12	3357011	<a href="#">308685</a>	Side Trim )
13	355274	<a href="#">W10119828</a>	Screw, Lid Hinge Mounting
15	8559336	<a href="#">W10225136</a>	Hinge 7 Pad Assembly
16	<a href="#">54583</a>		Hinge, Lid
17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">8319539</a>		Bearing, Lid Hinge
19	8558398	<a href="#">W10193861</a>	Lid
28	<a href="#">3390631</a>		Screw, 10-16 X 3/8
31	<a href="#">3955788</a>		Cover, Dispenser
32	<a href="#">8519517</a>		Dispenser, Bleach

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>