


Whirlpool LSN1000PQ0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool Residential Whirlpool LSN1000PQ0 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	694419			Mini-Buzzer
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	3400073			Screw, Ground
5	8318255	8568314		Strap, Console
6	3357978			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	8557301			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping

12	3366845	W10339326	Switch-WL
13	3948608		Bracket, Control
14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
18	3952164	285805	Valve-Inlet
19	303294	3367669	Protector, Edge
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8055003		Clip, Harness And Pressure Switch
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
26	8317940	W10358149	Drain Hose Assembly
27	3366912	356138	Clamp, Hose
28	661606	8572717	Capacitor, Motor Start
29	8317975		Restraint, Harness
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3976395		Restraint, Hose
34	3949180	W10168257	Switch, Rotary
35	62863	3390631	Screw, 10-16 X 3/8
36	3400818		Screw, Timer Mounting
38	661612	W10168256	Switch, Water Temperature
39	3956569		Panel, Console
43	8541607	3357328	Hose, Vacuum Break
44	8544943		Knob, Timer
45	8544947		Dial, Timer
46	8544935		Knob, Control
47	8536939		Clip, Knob
49	388326		Screw, 8-18 X 1.25
50	9740848		Screw, Mixing Valve Mounting
51	8271359	279962	Endcap
53	3357027		Nozzle, Hose Drain
54	3366913	3357331	Clamp, Drain
55	8539874		Shield, Suds
56	3957019		Harness, Wiring

