


Whirlpool LSN3000PW1 04 - BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LSN3000PW1, LSN3000PG1
(White/Grey) (Biscuit/Gold)



8180561

7

Whirlpool [Residential Whirlpool LSN3000PW1 Washer Parts](#) Parts Diagram 04 - BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	388952	285792		Basketdrive
2	63292			Washer, Spin Tube Thrust
3	62697	W10080230		Ring, Spin Tube Support
4	63283	285353		Ring
5	3951311	285785		Clutch
6	3951308	285790		Lining
7	62646			Cap, Clutch Spring
8	3946792			Spring And Damper Assembly
9	3360630	3360629		Gearcase
10	3357334	3400516		Screw Anti-Rattle
11	62611			Plate, Motor Mount To Gearcase
12	62691			Grommet, Motor
13	285753	285753A		Coupling
15	3355454			Clip, Main Drive

16	3400516		Screw Anti-Rattle
17	3349637	W10086010	Retainer, Motor
18	3362089		Shield, Tub To Motor
19	8529935		Motor, Main Drive
20	8529896		Switch, Main Drive Motor
21	8546127		Retainer, Pump
22	3363394		Pump
23	3387485	273556	Screw, 10-16 X 5/8
24	3946532		Shield, Motor

