


# Whirlpool LSQ9010LW3 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Models: LSQ9010LW3, LSQ9010LG3  
(White/Grey) (Biscuit/Gold)

AUTOMATIC  
WASHER



11-03 Litho in U.S.A. (drd)

1

Part No. 8180174

[Whirlpool Residential Whirlpool LSQ9010LW3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955907		Not Available	Literature Parts (Feature Sheet)
"	<a href="#">LIT3955869</a>			Literature Parts
"	LIT3956339		Not Available	Literature Parts (Energy Guide)
"	LIT8541273		Not Available	Literature Parts (Wiring Diagram)
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT4313896	<a href="#">4313896</a>		Do-It-Yourself Repair Manuals
2	<a href="#">3955792</a>			Top
"	<a href="#">3955793</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
"	<a href="#">3954357</a>			Cabinet

6	<a href="#">62780</a>		Clip, Top And Cabinet And Rear Panel
7	<a href="#">3976348</a>		Absorber, Sound
8	<a href="#">3400611</a>		Screw And Washer, Lid Switch
9	3357011	<a href="#">308685</a>	Side Trim )
10	<a href="#">8054939</a>		Seal, Lid
11	<a href="#">8054980</a>		Switch, Lid
13	355274	<a href="#">W10119828</a>	Screw, Lid Hinge Mounting
15	<a href="#">8055257</a>		Hinge, Lid
16	<a href="#">8055256</a>		Hinge, Lid
17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">8319539</a>		Bearing, Lid Hinge
19	3956016	<a href="#">3957547</a>	Lid
"	3956017	<a href="#">3957548</a>	Lid
22	<a href="#">3351614</a>		Screw, Gearcase Cover Mounting
28	<a href="#">3390631</a>		Screw, 10-16 X 3/8
31	<a href="#">3955788</a>		Cover, Dispenser
32	<a href="#">8519517</a>		Dispenser, Bleach

