


Whirlpool LSQ9549LW3 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: LSQ9549LQ3, LSQ9549LW3, LSQ9549LG3
(Designer White) (White/Grey) (Biscuit/Gold)

AUTOMATIC
WASHER



11-03 Litho in U.S.A. (dtd)

1

Part No. 8180176

[Whirlpool Residential Whirlpool LSQ9549LW3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955907		Not Available	Literature Parts (Feature Sheet)
"	LIT3955869			Literature Parts
"	LIT3956339		Not Available	Literature Parts (Energy Guide)
"	LIT8558184		Not Available	Literature Parts (Wiring Diagram)
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT4313896	4313896		Do-It-Yourself Repair Manuals
2	3955792			Top
"	3955793			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
"	3954357			Cabinet

6	62780		Clip, Top And Cabinet And Rear Panel
7	3976348		Absorber, Sound
8	3400611		Screw And Washer, Lid Switch
9	3357011	308685	Side Trim)
10	8054939		Seal, Lid
11	8054980		Switch, Lid
13	355274	W10119828	Screw, Lid Hinge Mounting
15	8055257		Hinge, Lid
16	8055256		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	8319539		Bearing, Lid Hinge
19	3956016	3957547	Lid
"	3956017	3957548	Lid
22	3351614		Screw, Gearcase Cover Mounting
28	3390631		Screw, 10-16 X 3/8
31	3955788		Cover, Dispenser
32	8519517		Dispenser, Bleach

