


# Whirlpool LSQ9650PW4 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Models: LSQ9650PW4, LSQ9650PG4  
(White/Grey) (Biscuit/Gold)

AUTOMATIC  
WASHER



11-05 Litho in U.S.A. (drd)

1

Part No. 8180919

Whirlpool [Residential Whirlpool LSQ9650PW4 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

| Item | Original Part Number    | Replaced By             | Status        | Part Description   |
|------|-------------------------|-------------------------|---------------|--|
| 1    | 3958075                 |                         | Not Available | Installation Instructions                                      |
| "    | 8578232                 |                         | Not Available | Use & Care Guide   |
| "    | 3955907                 |                         | Not Available | Feature Sheet  |
| "    | 3957351                 |                         | Not Available | Energy Guide   |
| "    | 8566206                 |                         | Not Available | Wiring Diagram   |
| "    | N/A                     |                         | Not Available | Following May Be Purchased<br>DO-IT-YOURSELF REPAIR<br>MANUALS |
| "    | <a href="#">4313896</a> |                         |               | Do-It-Yourself Repair Manuals                                  |
| 2    | 8543451                 | <a href="#">8543447</a> |               | Top  |
| "    | 8543452                 | <a href="#">8543448</a> |               | Top  |
| 3    | 62750                   |                         |               | Spacer, Cabinet To Top (4)                                     |
| 4    | <a href="#">357213</a>  |                         |               | Nut, Push-In   |
| 5    | <a href="#">63424</a>   |                         |               | Cabinet  |
| "    | <a href="#">3954357</a> |                         |               | Cabinet  |
| 6    | <a href="#">62780</a>   |                         |               | Clip, Top And Cabinet And<br>Rear Panel                        |

|    |                         |                           |                                |
|----|-------------------------|---------------------------|--------------------------------|
| 7  | <a href="#">3976348</a> |                           | Absorber, Sound                |
| 8  | <a href="#">3351614</a> |                           | Screw, Gearcase Cover Mounting |
| 9  | 3357011                 | <a href="#">308685</a>    | Side Trim )                    |
| 10 | <a href="#">9724509</a> |                           | Bumper, Lid                    |
| 11 | <a href="#">8318084</a> |                           | Switch, Lid                    |
| 13 | 355274                  | <a href="#">W10119828</a> | Screw, Lid Hinge Mounting      |
| 14 | <a href="#">21097</a>   |                           | Pad, Lid Hinge                 |
| 15 | 8559336                 | <a href="#">W10225136</a> | Hinge 7 Pad Assembly           |
| 16 | <a href="#">91770</a>   |                           | Hinge, Lid                     |
| 18 | <a href="#">8319539</a> |                           | Bearing, Lid Hinge             |
| 19 | 8558398                 | <a href="#">W10193861</a> | Lid                            |
| "  | 8558399                 | <a href="#">W10193862</a> | Lid                            |
| 28 | <a href="#">3390631</a> |                           | Screw, 10-16 X 3/8             |
| 31 | <a href="#">3955788</a> |                           | Cover, Dispenser               |
| 32 | <a href="#">8519517</a> |                           | Dispenser, Bleach              |

