


Whirlpool LSQ9659PW3 09 - WATER SYSTEM PARTS, MISCELLANEOUS PARTS, OPTIONAL PARTS (NOT INCLUDED)

WATER SYSTEM PARTS

For Models: LSQ9659PW3, LSQ9659PG3
(White/Grey) (Biscuit/Gold)



8180660

13

Whirlpool [Residential Whirlpool LSQ9659PW3 Washer Parts](#) Parts Diagram 09 - WATER SYSTEM PARTS, MISCELLANEOUS PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	285442			Water System Parts
2	285321			Water System Parts
3	370447	285655		Clamp, Hose
4	16272			Connector, Straight
5	285320			Water System Parts
6	65349	285655		Clamp, Hose
7	367031			Water System Parts
1	3957361			Miscellaneous Parts Bag
2	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
3	3359452			Nut, Lock
4	389102	W10001130		Foot, Leveling
	72017			Paint, Touch-Up
"	4392899			Paint, Touch-Up

"	350938		Paint, Pressurized Spray B
"	350930		Paint, Pressurized Spray B
"	4392901		Paint, Pressurized Spray
"	799344		Paint, Touch-Up)
"	4392900		Paint, Bulk)
"	N/A	Not Available	OIL
"	350572		Oil
"	N/A	Not Available	LUBRICANT
"	285208		Lubricant
"	N/A	Not Available	SEALER
"	285195		Sealer Sealer, Gasket
"	N/A	Not Available	ACCESSORY PARTS
"	367031		Water System Parts
"	285320		Water System Parts

the laundry company[®]

the laundry company[®]

the laundry company[®]