

Whirlpool LSQ9660PG3 06 - WIRING HARNESS PARTS

WIRING HARNESS PARTS

For Models: LSQ9660PW3, LSQ9660PG3
(White/Grey) (Biscuit/Gold)



WH21

8180661

9

Whirlpool [Residential Whirlpool LSQ9660PG3 Washer Parts](#) Parts Diagram 06 - WIRING HARNESS PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3349557			Retainer, Harness
2	388498		Not Available	Clip, Harness
3	3347812	8528351		Clip
4	3352501	8559320		Restraint, Hose
5	90016			Clip, Pressure Switch Hose
6	3390496	8281256		Clip, Harness
7	389379			Retainer, Side To Feature Panel
8	3948614			Disconnect Block
"	352089			Timer, Block Disconnect
9	62889			Receptacle, Terminal
10	353424			Plug, Terminal
11	62505			Block, Disconnect
12	3347243			Block, Disconnect
13	63523			Harness, Protector
14	717252			Receptacle, Terminal
15	3352944			Clip, Harness

16	3390423	Not Available	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)
17	3347730	Not Available	Receptacle, (6-Way) (Use Term. 94613)
18	3349494		Connector, Etc
19	3407125	3955728	Control, Etc
20	3948617	2172937	Connector
21	3360056		Connector
22	3354925		Block, Connector
"	3354926		Block, Connector

