


Whirlpool LSR5132PQ1 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: LSR5132PQ1
(Designer White)

AUTOMATIC
WASHER



5-05 Litho in U.S.A. (drd)

1

Part No. 8180668

[Whirlpool Residential Whirlpool LSR5132PQ1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3957165		Not Available	Installation Instructions
"	3955901		Not Available	Feature Sheet
"	3955869		Not Available	Use & Care Guide
"	3957356		Not Available	Energy Guide
"	8546683		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	8318068			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3351614			Screw, Gearcase Cover Mounting

11	8318084		Switch, Lid
13	3351355	W10119828	Screw, Lid Hinge Mounting
15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542383	W1019385Z	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

