


Whirlpool LSR6334LQ1 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: LSR6334LQ1
(Designer White)

AUTOMATIC
WASHER



1-04 Litho in U.S.A. (dtd)

1

Part No. 8180203

Whirlpool [Residential Whirlpool LSR6334LQ1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955901		Not Available	Literature Parts (Feature Sheet)
"	LIT3955869			Literature Parts
"	LIT3955498		Not Available	Literature Parts (Wiring Diagram)
"	LIT3956913		Not Available	Literature Parts (Energy Guide)
"	N/A		Not Available	Following May Be Purchased
"	N/A		Not Available	DO-IT-YOURSELF REPAIR MANUALS
"	LIT4313896	4313896		Do-It-Yourself Repair Manuals
2	8271378			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel

7	3357011	308685	Side Trim)
8	3356311		Screw And Washer, Lid Switch Shield
9	3362952		Dispenser, Bleach
11	3949237	3949247	Switch-Lid
13	3351355	W10119828	Screw, Lid Hinge Mounting
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3954489	W10193874	Lid
20	358684		Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	90016		Clip, Pressure Switch Hose

