


Whirlpool LSR7133KQ1 03 - AGITATOR, BASKET AND TUB PARTS



8179964

5

Whirlpool [Residential Whirlpool LSR7133KQ1 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	64210			Extension, Agitator
3	63027	W10109200		Screw, Baffle Mounting
4	358237			Screw And Washer
5	64214			Agitator
6	8528150	W10445870		Ring-Tub
7	3359585	3976308		Gasket, Tub Ring
8	21366			Nut, Spanner
9	8526017	W10389329		Clothes Container, Assembly
10	8519788	387240		Ring, Balance
11	63849			Strain Relief, Power Cord
13	389140			Tub Block, Basket Drive
14	383727			Gasket, Centerpod
15	3347780	353244		Hose, Pressure Switch
26	3949550			Washer