


# Whirlpool LSR8433KT2 02 - CONTROLS AND REAR PANEL PARTS

## CONTROLS AND REAR PANEL PARTS

For Models: LSR8433KQ2, LSR8433KT2  
(Designer White) (Biscuit)



8180207

3

Whirlpool Residential Whirlpool LSR8433KT2 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	<a href="#">16123</a>		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	<a href="#">3400073</a>			Screw, Ground
3	3949374	<a href="#">89503</a>		Hose-Inlet
"	3949375	<a href="#">89503</a>		Hose-Inlet
4	<a href="#">9740848</a>			Screw, Mixing Valve Mounting
5	8318255	<a href="#">8568314</a>		Strap, Console
6	<a href="#">3357978</a>			Panel, Rear
7	<a href="#">62747</a>			Pad, Rear Panel
8	3951609	<a href="#">285664</a>		Hose
"	661577	<a href="#">285666</a>		Hose
"	3357090	<a href="#">285702</a>		Hose
9	<a href="#">8542050</a>			Timer, Control
10	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
11	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping

12	3366848	<a href="#">W10339229</a>	Switch-WL
13	<a href="#">3948608</a>		Bracket, Control
14	661661	<a href="#">285800</a>	Cord-Power
15	3952821	<a href="#">285777</a>	Relief-Str
16	8271365	<a href="#">279962</a>	Endcap
"	8271368	<a href="#">279965</a>	Endcap
17	661606	<a href="#">8572717</a>	Capacitor, Motor Start
18	3952164	<a href="#">285805</a>	Valve-Inlet
19	<a href="#">3976286</a>		Shield, Capacitor
20	8318201	<a href="#">8318046</a>	Clip, Capacitor
21	301958	<a href="#">596669</a>	Clamp, Manifold
22	8541607	<a href="#">3357328</a>	Hose, Vacuum Break
23	370450	<a href="#">596669</a>	Clamp, Manifold
24	387606	<a href="#">3360977</a>	Break-Vac
25	303294	<a href="#">3367669</a>	Protector, Edge
26	8317940	<a href="#">W10358149</a>	Drain Hose Assembly
27	3366912	<a href="#">356138</a>	Clamp, Hose
28	<a href="#">3976395</a>		Restraint, Hose
29	<a href="#">8317975</a>		Restraint, Harness
30	3363366	<a href="#">616099</a>	Clamp
31	8317496	<a href="#">285655</a>	Clamp, Hose
32	3951449	<a href="#">285871</a>	Hose
33	<a href="#">8055003</a>		Clip, Harness And Pressure Switch
35	661612	<a href="#">W10168256</a>	Switch, Water Temperature
36	<a href="#">3400818</a>		Screw, Timer Mounting
39	<a href="#">3955356</a>		Panel, Console
"	<a href="#">3955357</a>		Panel, Console
44	8271345	<a href="#">3957824</a>	Knob, Timer
"	8271347	<a href="#">3957822</a>	Knob, Timer
45	8271351	<a href="#">3957849</a>	Dial, Timer
"	8271370	<a href="#">3957850</a>	Dial, Timer
47	8271339	<a href="#">3957799</a>	Knob, Control
"	8271348	<a href="#">3957797</a>	Knob, Push-To-Start
49	<a href="#">388326</a>		Screw, 8-18 X 1.25
50	62863	<a href="#">3390631</a>	Screw, 10-16 X 3/8
51	8271359	<a href="#">279962</a>	Endcap
"	8271362	<a href="#">279965</a>	Endcap
55	3347812	<a href="#">8528351</a>	Clip
58	3366913	<a href="#">3357331</a>	Clamp, Drain
59	<a href="#">8539874</a>		Shield, Suds
60	<a href="#">3357027</a>		Nozzle, Hose Drain
61	<a href="#">3956952</a>		Harness, Wiring

*the laundry company*<sup>®</sup>