


Whirlpool LSR8444LQ1 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool LSR8444LQ1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955869			Literature Parts
"	LIT3955901		Not Available	Literature Parts (Feature Sheet)
"	LIT3956340		Not Available	Literature Parts (Energy Guide)
"	LIT8541395		Not Available	Literature Parts (Wiring Diagram)
"	N/A		Not Available	Following May Be Purchased
"	N/A		Not Available	DO-IT-YOURSELF REPAIR MANUALS
"	LIT4313896	4313896		Do-It-Yourself Repair Manuals
2	8318064			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel

7	3362952		Dispenser, Bleach
8	3351614		Screw, Gearcase Cover Mounting
9	3357011	308685	Side Trim)
11	8318084		Switch, Lid
13	3351355	W10119828	Screw, Lid Hinge Mounting
15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542387	W10193857	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

the laundry company[®]

the laundry company[®]

the laundry company[®]