


# Whirlpool LSR8444LQ1 06 - WIRING HARNESS PARTS

## WIRING HARNESS PARTS

For Model: LSR8444LQ1  
(Designer White)



WH2G

8180108

9

[Whirlpool Residential Whirlpool LSR8444LQ1 Washer Parts](#) Parts Diagram 06 - WIRING HARNESS PARTS

[Click on the part number to view part](#)

| Item | Original Part Number    | Replaced By             | Status        | Part Description   |
|------|-------------------------|-------------------------|---------------|--|
| 1    | <a href="#">3349557</a> |                         |               | Retainer, Harness  |
| 2    | 388498                  |                         | Not Available | Clip, Harness  |
| 3    | 3347812                 | <a href="#">8528351</a> |               | Clip   |
| 4    | 3352501                 | <a href="#">8559320</a> |               | Restraint, Hose  |
| 5    | <a href="#">90016</a>   |                         |               | Clip, Pressure Switch Hose                                   |
| 6    | 3390496                 | <a href="#">8281256</a> |               | Clip, Harness  |
| 7    | <a href="#">389379</a>  |                         |               | Retainer, Side To Feature Panel                              |
| 8    | <a href="#">352090</a>  |                         |               | Timer, Block Disconnect                                      |
| 9    | <a href="#">352089</a>  |                         |               | Timer, Block Disconnect                                      |
| 10   | <a href="#">62889</a>   |                         |               | Receptacle, Terminal   |
| 11   | <a href="#">353424</a>  |                         |               | Plug, Terminal   |
| 12   | <a href="#">62505</a>   |                         |               | Block, Disconnect  |
| 13   | 3348075                 |                         |               | Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614) |
| 14   | <a href="#">3347243</a> |                         |               | Block, Disconnect  |

|    |                         |                         |   |
|----|-------------------------|-------------------------|---|
| 15 | <a href="#">63523</a>   |                         | Harness, Protector  |
| 16 | <a href="#">717252</a>  |                         | Receptacle, Terminal  |
| 17 | 387566                  |                         | Plug, Terminal (4-Way) (Power Cord) (Use M3 Screws)                           |
| 18 | <a href="#">3352944</a> |                         | Clip, Harness   |
| 19 | 3390423                 | Not Available           | Block, Disconnect (12-Way) (Timer) (Use Term. 94613)                          |
| 20 | 3347730                 | Not Available           | Receptacle, (6-Way) (Use Term. 94613)   |
| 21 | 388818                  |                         | Plug, Terminal (12-Way) (Use Term. 94613 Or 94614)                            |
| 22 | 3369366                 | Not Available           | Timer, Block Disconnect (Black) (Amp) (Use Term. 3369365)                     |
| 23 | 3349494                 |                         | Connector, Etc  |
| 24 | 60687                   |                         | Connector, Relay (Use Term. 308569)   |
| 25 | 3407125                 | <a href="#">3955728</a> | Control, Etc  |
| 26 | 3948617                 | <a href="#">2172937</a> | Connector   |
| 27 | <a href="#">3360056</a> |                         | Connector   |
| 28 | <a href="#">3354925</a> |                         | Block, Connector  |
| 29 | <a href="#">3354926</a> |                         | Block, Connector  |
| 30 | 3948615                 | Not Available           | Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term. 3948619 OR 3948620.) |

