


Whirlpool LSR9434PT3 01 - TOP AND CABINET PARTS



10-05 Litho in U.S.A. (dtd)

1

Part No. 8180838

Whirlpool Residential Whirlpool LSR9434PT3 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------|---------------|--------------------------------------|
| 1 | 3956025 | | Not Available | Installation Instructions |
| " | 3955869 | | Not Available | Use & Care Guide |
| " | 3955907 | | Not Available | Feature Sheet |
| " | 3957470 | | Not Available | Energy Guide |
| " | 8541944 | | Not Available | Wiring Diagram |
| " | N/A | | Not Available | Following May Be Purchased |
| " | N/A | | Not Available | DO-IT-YOURSELF REPAIR MANUALS |
| " | 4313896 | | | Do-It-Yourself Repair Manuals |
| 2 | 8318064 | | | Top |
| " | 8318066 | | | Top |
| 3 | 62750 | | | Spacer, Cabinet To Top (4) |
| 4 | 357213 | | | Nut, Push-In |
| 5 | 63424 | | | Cabinet |
| " | 3954357 | | | Cabinet |
| 6 | 62780 | | | Clip, Top And Cabinet And Rear Panel |

| | | | |
|----|-------------------------|---------------------------|--------------------------------|
| 7 | 3362952 | | Dispenser, Bleach |
| 8 | 3351614 | | Screw, Gearcase Cover Mounting |
| 9 | 3357011 | 308685 | Side Trim) |
| 11 | 8318084 | | Switch, Lid |
| 13 | 3351355 | W10119828 | Screw, Lid Hinge Mounting |
| 15 | 8318088 | | Hinge, Lid |
| 16 | 54583 | | Hinge, Lid |
| 17 | 19119 | | Bumper, Lid Hinge |
| 18 | 21258 | | Bearing, Lid Hinge |
| 19 | 8542387 | W10193857 | Lid |
| " | 8542384 | 3957520 | Lid |
| 22 | 9724509 | | Bumper, Lid |
| 28 | 3390631 | | Screw, 10-16 X 3/8 |

the laundry company[®]

the laundry company[®]

the laundry company[®]