


Whirlpool LSW9750PW0 01 - TOP AND CABINET PARTS



06-04 Litho in U.S.A. (drd)

1

Part No. 8180455

[Whirlpool Residential Whirlpool LSW9750PW0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3956025		Not Available	Installation Instructions
"	3955922		Not Available	Feature Sheet
"	3955869		Not Available	Use & Care Guide
"	3956915		Not Available	Energy Guide
"	8564019		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	3955792			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3400611			Screw And Washer, Lid Switch
8	3351614			Screw, Gearcase Cover Mounting

9	3976348		Absorber, Sound
10	3357011	308685	Side Trim)
11	8054980		Switch, Lid
13	355274	W10119828	Screw, Lid Hinge Mounting
15	8055257		Hinge, Lid
16	8055256		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	8319539		Bearing, Lid Hinge
19	8558398	W10193861	Lid
20	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	3955788		Cover, Dispenser
32	8519517		Dispenser, Bleach

the laundry company[®]

the laundry company[®]

the laundry company[®]