


# Whirlpool LTE5243DQ4 01 - WASHER/DRYER CONTROL PANEL PARTS



11-04 Litho in U.S.A. (djc)

1

Part No. 8180580

Whirlpool [Residential Whirlpool LTE5243DQ4 Washer/Dryer Parts](#) Parts Diagram 01 - WASHER/DRYER CONTROL PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8542748		Not Available	Installation Instructions
"	3406880		Not Available	Installation Instructions (English)
"	3954159		Not Available	Energy Guide
"	8542754		Not Available	Sheet, Cycle Feature
"	3952874		Not Available	Wiring Diagram
2	<a href="#">3406288</a>			Harness, Console Wiring
"	<a href="#">3350130</a>			Plug, Terminal
"	<a href="#">696073</a>			Receptacle, Connector
"	<a href="#">3948614</a>			Disconnect Block
5	<a href="#">3952499</a>			Timer, Control
6	<a href="#">8528154</a>			Bracket, Control
7	<a href="#">692993</a>			End Cap, Console
"	<a href="#">3978584</a>			End Cap, Console
8	<a href="#">348689</a>			Screw, End Cap Mounting
9	<a href="#">694091</a>			Trim, Side Right Hand

10	<a href="#">3362987</a>		Switch, Water Level
12	<a href="#">8054142</a>		Switch, Water Temperature
14	<a href="#">693151</a>		Spring, Console Lock
15	<a href="#">3400860</a>		Screw, Console Lock
16	<a href="#">3406720</a>		Timer, Control
18	<a href="#">3977456</a>		Switch, Push-To-Start
19	<a href="#">693152</a>		Bumper, Console
21	<a href="#">694037</a>		Clip, Console
22	3390646	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
23	<a href="#">3977194</a>		Panel, Control
"	<a href="#">3977195</a>		Panel, Control
24	3406143	<a href="#">3957752</a>	Knob, Timer
"	3978872	<a href="#">3957753</a>	Knob, Timer
25	3406133	<a href="#">3957800</a>	Knob, Push-To-Start
"	<a href="#">3978871</a>		Knob, Push-To-Start
27	3950759	<a href="#">3957796</a>	Knob, Control
"	3978873	<a href="#">3957797</a>	Knob, Push-To-Start
28	3950762	<a href="#">3957841</a>	Dial, Timer
"	3978870	<a href="#">3957842</a>	Dial, Timer
29	3951026	<a href="#">3957821</a>	Knob, Timer
"	3978869	<a href="#">3957822</a>	Knob, Timer
31	<a href="#">692983</a>		Lock, Console
32	<a href="#">694419</a>		Mini-Buzzer

