


Whirlpool LTE5243DQ4 03 - DRYER CABINET AND MOTOR PARTS

DRYER CABINET AND MOTOR PARTS

For Models: LTE5243DQ4, LTE5243DT4
(Designer White) (Biscuit)



8180580

3

Whirlpool [Residential Whirlpool LTE5243DQ4 Washer/Dryer Parts](#) Parts Diagram 03 - DRYER CABINET AND MOTOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	660658			Clamp, Motor Mounting 343481 685441
2	8538265	8539558		Motor-Drive
5	696541			Bracket, Motor
6	3390405	280069		Panel
7	343641	681414		Screw, 10AB X 1/2
8	3394228			Cover, Terminal Block
9	90296			Nut, Push On
10	3402293			Panel, Side
"	3978589			Panel, Side
14	3399602			Elbow, Upper
15	3394083			Clip, Front Panel
16	98234			Clip, U-Bend
17	3399603			Elbow, Lower
18	686770	686769		Protector, Support
20	8066064	3394652		Belt, Drive

21	8066051		Pulley, Motor
22	691366		Idler And Pulley Assembly
23	692771		Nut, Idler Bracket To Base
24	3399632		Base, Dryer
25	692400		Nut, Push-In
26	692926		Cove, Transition Panel
27	692933		Panel, Transition
"	3978591		Panel, Transition
28	692641		Top, Dryer
29	3402287		Panel, Side
"	3978590		Panel, Side
30	693145		Latch, Lid
31	692781		Closure, Control Area
"	3978599		Closure, Control Area
32	354975		Screw And Washer
33	693304		Screw And Washer
34	697776	4331106	Screw, No.10-32 X 7/16
35	3390631		Screw, 10-16 X 3/8
36	661606	8572717	Capacitor, Motor Start
37	357030		Clamp, Capacitor

