


Whirlpool LTE5243DQ4 07 - WASHER CABINET PARTS

WASHER CABINET PARTS

For Models: LTE5243DQ4, LTE5243DT4
(Designer White) (Biscuit)



8180580

9

Whirlpool [Residential Whirlpool LTE5243DQ4 Washer/Dryer Parts](#) Parts Diagram 07 - WASHER CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	356746			Clip, Condenser
2	343641	681414		Screw, 10AB X 1/2
3	9740848			Screw, Mixing Valve Mounting
4	370451	596669		Clamp, Manifold
5	3952163	285805		Valve-Inlet
7	692699			Hose, Water Inlet
8	696013			Cabinet
"	3978594			Cabinet
10	696710			Hose, Drain
11	692400			Nut, Push-In
12	660975			Plug, Top To Cabinet
13	8557915			Connector, Hose
15	356471			Cap, Siphon Break
16	356363			Siphon Break
17	272861		Not Available	Clamp, Hose
18	696394			Hose, Water Inlet

21	660628	285655	Clamp, Hose
22	3394083		Clip, Front Panel
23	358652		Link, Leveling
24	359364		Clip, Leveling Mechanism
25	98234		Clip, U-Bend
26	345670		Lock, Top
27	692628		Panel, Front
"	3978596		Panel, Front
28	367594		Foot, Front
29	358594		Foot, Rear
30	3400000		Screw, 10-24 X 3/8
32	3390046		Protector, Edge

the laundry company[®]

the laundry company[®]

the laundry company[®]