


# Whirlpool LTE5243DQ7 02 - DRYER FRONT PANEL AND DOOR PARTS

## DRYER FRONT PANEL AND DOOR PARTS

For Models: LTE5243DQ7, LTE5243DT7  
(Designer White) (Biscuit)



Whirlpool Residential Whirlpool LTE5243DQ7 Washer/Dryer Parts Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

[Click on the part number to view part](#)

| Item | Original Part Number    | Replaced By             | Status | Part Description    |
|------|-------------------------|-------------------------|--------|---------------------|
| 1    | <a href="#">3406108</a> |                         |        | Door Switch         |
| 2    | 697773                  | <a href="#">3395530</a> |        | Screw               |
| 4    | 692619                  | <a href="#">285314</a>  |        | Panel               |
| "    | 3978587                 | <a href="#">285836</a>  |        | Panel               |
| 5    | <a href="#">3390734</a> |                         |        | Seal, Door          |
| 6    | 695656                  | <a href="#">280077</a>  |        | Door                |
| 7    | <a href="#">348205</a>  |                         |        | Door, Front         |
| "    | <a href="#">3978598</a> |                         |        | Door, Front         |
| 9    | 8066123                 | <a href="#">279264</a>  |        | Air Channel Box     |
| 10   | 685203                  | <a href="#">279220</a>  |        | Clip                |
| 11   | 696144                  | <a href="#">279570</a>  |        | Latch               |
| 12   | 3390663                 | <a href="#">681414</a>  |        | Screw, 10AB X 1/2   |
| 13   | 343641                  | <a href="#">681414</a>  |        | Screw, 10AB X 1/2   |
| 14   | <a href="#">3389441</a> |                         |        | Door Catch Assembly |
| 15   | <a href="#">686711</a>  |                         |        | Handle, Door        |
| "    | <a href="#">3978592</a> |                         |        | Handle, Door        |

