


Whirlpool LTE5243DQ8 01 - WASHER/DRYER CONTROL PANEL PARTS



1-09 Litho in U.S.A.(LT) (psw)

1

Part No. W10248252 Rev. A

Whirlpool [Residential Whirlpool LTE5243DQ8 Washer/Dryer Parts](#) Parts Diagram 01 - WASHER/DRYER CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10222387		Not Available	Installation Instructions
"	W10196553		Not Available	Guide, Use & Care
"	W10194037		Not Available	Energy Guide
"	8542754		Not Available	Sheet, Cycle Feature
"	8576808		Not Available	Wiring Diagram
2	8577368			Harness, Console Wiring
"	3350130			Plug, Terminal
"	696073			Receptacle, Connector
"	3948614			Disconnect Block
5	3952499			Timer, Control
6	8528154			Bracket, Control
7	692993			End Cap, Console
8	348689			Screw, End Cap Mounting
9	694091			Trim, Side Right Hand
10	3362987			Switch, Water Level
11	688805			Clip, Spring Knob

12	8054142		Switch, Water Temperature
14	693151		Spring, Console Lock
15	3400860		Screw, Console Lock
16	3406720		Timer, Control
18	3977456		Switch, Push-To-Start
19	693152		Bumper, Console
21	694037		Clip, Console
22	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
23	3977194		Panel, Control
24	3957752		Knob, Timer
25	3957800		Knob, Push-To-Start
27	3957796		Knob, Control
28	3957841		Dial, Timer
29	3957821		Knob, Timer
31	692983		Lock, Console
32	694419		Mini-Buzzer

