


Whirlpool LTE5243DQ8 02 - DRYER FRONT PANEL AND DOOR PARTS

DRYER FRONT PANEL AND DOOR PARTS

For Models: LTE5243DQ8
(Designer White)



2

W10248252

Whirlpool Residential Whirlpool LTE5243DQ8 Washer/Dryer Parts Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3406108			Door Switch
2	697773	3395530		Screw
4	692619	285314		Panel
5	3390734			Seal, Door
6	695656	280077		Door
7	348205			Door, Front
9	8066123	279264		Air Channel Box
10	685203	279220		Clip
11	696144	279570		Latch
12	3390663	681414		Screw, 10AB X 1/2
13	343641	681414		Screw, 10AB X 1/2
14	3389441			Door Catch Assembly
15	686711			Handle, Door
19	694091			Trim, Side Right Hand
20	348023			Hinge And Pin Assembly