


Whirlpool LTE5243DQ9 03 - DRYER CABINET AND MOTOR PARTS



Whirlpool Residential Whirlpool LTE5243DQ9 Washer/Dryer Parts Parts Diagram 03 - DRYER CABINET AND MOTOR PARTS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|-------------------------|--------|------------------------|
| 1 | W10121316 | | | Plug, Multivent |
| 2 | 8538265 | 8539558 | | Motor-Drve |
| 3 | 3393657 | | | Restrainer, Belt |
| 4 | 693304 | | | Screw And Washer |
| 5 | 696541 | | | Bracket, Motor |
| 6 | 3390405 | 280069 | | Panel |
| 7 | 343641 | 681414 | | Screw, 10AB X 1/2 |
| 8 | 3394228 | | | Cover, Terminal Block |
| 9 | 90296 | | | Nut, Push On |
| 10 | 3402293 | | | Panel, Side |
| 11 | 697776 | 4331106 | | Screw, No.10-32 X 7/16 |
| 12 | 3390631 | | | Screw, 10-16 X 3/8 |
| 13 | 8572717 | | | Capacitor, Motor Start |
| 14 | 3399602 | | | Elbow, Upper |
| 15 | 3394083 | | | Clip, Front Panel |
| 16 | 98234 | | | Clip, U-Bend |

| | | | |
|----|-------------------------|----------------------------|--------------------|
| 17 | 3399603 | Elbow, Lower | |
| 18 | 686770 | 686769 | Protector, Support |
| 19 | 357030 | Clamp, Capacitor | |
| 20 | 8066064 | 3394652 | Belt, Drive |
| 21 | 8066051 | Pulley, Motor | |
| 22 | 691366 | Idler And Pulley Assembly | |
| 23 | 692771 | Nut, Idler Bracket To Base | |
| 24 | 3399632 | Base, Dryer | |
| 25 | 692400 | Nut, Push-In | |
| 26 | 692926 | Cove, Transition Panel | |
| 27 | 692933 | Panel, Transition | |
| 28 | 692641 | Top, Dryer | |
| 29 | 3402287 | Panel, Side | |
| 30 | 693145 | Latch, Lid | |
| 31 | 692781 | Closure, Control Area | |
| 32 | 354975 | Screw And Washer | |

