


Whirlpool LTE5243DT5 01 - WASHER/DRYER CONTROL PANEL PARTS



8-05 Litho in U.S.A. (LT)

1

Part No. 8180758

Whirlpool Residential Whirlpool LTE5243DT5 Washer/Dryer Parts Parts Diagram 01 - WASHER/DRYER CONTROL PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8542748		Not Available	Installation Instructions
"	3406880		Not Available	Installation Instructions (English)
"	3954161		Not Available	Energy Guide
"	8542754		Not Available	Sheet, Cycle Feature
"	3952874		Not Available	Wiring Diagram
2	3406288			Harness, Console Wiring
"	3350130			Plug, Terminal
"	696073			Receptacle, Connector
"	3948614			Disconnect Block
5	3952499			Timer, Control
6	8528154			Bracket, Control
7	692993			End Cap, Console
"	3978584			End Cap, Console
8	348689			Screw, End Cap Mounting
9	694091			Trim, Side Right Hand

10	3362987		Switch, Water Level
11	688805		Clip, Spring Knob
12	8054142		Switch, Water Temperature
14	693151		Spring, Console Lock
15	3400860		Screw, Console Lock
16	3406720		Timer, Control
18	3977456		Switch, Push-To-Start
19	693152		Bumper, Console
21	694037		Clip, Console
22	3390646	W10139210	Screw, 8-18 X 5/16
23	3977194		Panel, Control
"	3977195		Panel, Control
24	3957752		Knob, Timer
"	3957753		Knob, Timer
25	3957800		Knob, Push-To-Start
"	3957801		Knob, Push-To-Start
27	3957796		Knob, Control
"	3957797		Knob, Push-To-Start
28	3957841		Dial, Timer
"	3957842		Dial, Timer
29	3957821		Knob, Timer
"	3957822		Knob, Timer
31	692983		Lock, Console
32	694419		Mini-Buzzer

