


Whirlpool LTE5243DT7 06 - WASHER TOP AND LID PARTS

WASHER TOP AND LID PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



8

W10116534

Whirlpool Residential Whirlpool LTE5243DT7 Washer/Dryer Parts Parts Diagram 06 - WASHER TOP AND LID PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3398848			Lid
"	3398849			Lid
2	384475	80011		Bumper
3	91770			Hinge, Lid
4	3351355	W10119828		Screw, Lid Hinge Mounting
5	343641	681414		Screw, 10AB X 1/2
6	692985			Clip, Spring
7	384693			Top
"	3978593			Top
8	21258			Bearing, Lid Hinge
9	3356311			Screw And Washer, Lid Switch Shield
10	358684			Strike, Lid Switch
11	3400030	33001178		Back, Tumbler
12	8533959	680762		Nut
13	3355806			Switch, Lid
14	90016			Clip, Pressure Switch Hose

