


# Whirlpool LTE5243DT7 07 - WASHER CABINET PARTS

## WASHER CABINET PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



W10116534

9

Whirlpool [Residential Whirlpool LTE5243DT7 Washer/Dryer Parts](#) Parts Diagram 07 - WASHER CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">356746</a>			Clip, Condenser
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">9740848</a>			Screw, Mixing Valve Mounting
4	370451	<a href="#">596669</a>		Clamp, Manifold
5	3952163	<a href="#">285805</a>		Valve-Inlet
7	<a href="#">692699</a>			Hose, Water Inlet
8	<a href="#">696013</a>			Cabinet
"	<a href="#">3978594</a>			Cabinet
10	<a href="#">696710</a>			Hose, Drain
11	<a href="#">692400</a>			Nut, Push-In
12	<a href="#">660975</a>			Plug, Top To Cabinet
13	<a href="#">8557915</a>			Connector, Hose
15	<a href="#">356471</a>			Cap, Siphon Break
16	<a href="#">356363</a>			Siphon Break
17	272861		Not Available	Clamp, Hose
18	<a href="#">696394</a>			Hose, Water Inlet

21	660628	<a href="#">285655</a>	Clamp, Hose
22	<a href="#">3394083</a>		Clip, Front Panel
23	<a href="#">358652</a>		Link, Leveling
24	<a href="#">359364</a>		Clip, Leveling Mechanism
25	<a href="#">98234</a>		Clip, U-Bend
26	<a href="#">345670</a>		Lock, Top
27	<a href="#">692628</a>		Panel, Front
"	<a href="#">3978596</a>		Panel, Front
28	<a href="#">367594</a>		Foot, Front
29	<a href="#">358594</a>		Foot, Rear
30	<a href="#">3400000</a>		Screw, 10-24 X 3/8
32	<a href="#">3390046</a>		Protector, Edge

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>