


Whirlpool LTE6234DQ3 01 - WASHER/DRYER CONTROL PANEL PARTS



10-03 Litho in U.S.A. (djc)

1

Part No. 8180161

Whirlpool [Residential Whirlpool LTE6234DQ3 Washer/Dryer Parts](#) Parts Diagram 01 - WASHER/DRYER CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8542746		Not Available	Literature Parts (Installation Instructions (English))
"	LIT3397634		Not Available	Literature Parts (Arabic Use & Care Guide)
"	LIT3406880		Not Available	Literature Parts (Installation Instructions (English))
"	LIT3405528		Not Available	Literature Parts (Arabic)
"	LIT8542752		Not Available	Literature Parts (Sheet, Cycle Feature)
"	LIT8546674		Not Available	Literature Parts (Wiring Diagram)
"	LIT3956353		Not Available	Literature Parts (Energy Guide)
2	3390688			Spacer- Foam Pad
3	8528583			Bracket, Control
4	3948357			Timer, Washer
5	3401674			Wire, Jumper
6	3403097	3957845		Dial,
"	3979132	3957846		Dial,

7	3364291		Knob, Timer
"	3364294		Knob, Timer
8	3950759	3957796	Knob, Control
"	3978873	3957797	Knob, Push-To-Start
9	3401078	279872	Resistor
10	3401684		Jumper, Wire
11	3406146	3957750	Knob, Timer
"	3978864	3957751	Knob, Timer
12	3400064		Screw, Timer Mounting
13	8546175	W10311356	Switch-WL
14	3405157		Switch, Temperature
15	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	3404233		Switch, Push-To-Start
17	3393810		Jumper Wire
18	694419		Mini-Buzzer
19	3976569		Timer, Dryer
20	3396689		Panel, Control
"	3406828		Panel, Control
21	3389453		Bracket, Hinge
22	3389456		End Cap
"	3389462		End Cap
23	8299835	8576535	Harns-Wire
"	2154470		Receptacle,
"	3395683		Receptacle, Multi-Terminal
24	3390604		Clamp, Harness
25	3390422	W10134185	Clip, Harness
29	3389464		End Cap
"	3389470		End Cap

